Color TV with built-in VCR

CCB092AT

Owner's Manual

Important!
Return your Warranty Registration Card within 10 days. See why inside.

PHILIPS

Return your Warranty Registration card today to ensure you receive all the benefits you're entitled to.

Once your PHILIPS purchase is registered, you're eligible to receive all the privileges of owning a PHILIPS product. So complete and return the Warranty Registration Card enclosed with your purchase at once. And take advantage of these important benefits.

Warranty Verification

Registering your product within 10 days confirms your right to maximum protection under the terms and conditions of your PHILIPS warranty.

Owner Confirmation

Your completed Warranty Registration Card serves as verification of ownership in the event of product theft or loss.

Model Registration

Returning your Warranty Registration Card right away guarantees you'll receive all the information and special offers which you qualify for as the owner of your model.

PHILIPS

Congratulations on your purchase, and welcome to the "family!"

Dear PHILIPS product owner:

Thank you for your confidence in PHILIPS. You've selected one of the best-built, best-backed products available today. And we'll do everything in our power to keep you happy with your purchase for many years to come.

As a member of the PHILIPS "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry.

What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.

And most importantly you can count on our uncompromising commitment to your total satisfaction.

All of this is our way of saying welcome-and thanks for investing in a PHILIPS product.

Sincerely,

Robert Minkhorst
President and Chief Executive Officer

P.S. Remember, to get the most from your PHILIPS product, you must return your Warranty Registration Card within 10 days. So please mail it to us right now!

Know these **safety** *symbols*

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

ATTENTION: Pour éviter les choc électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

For Customer Use

Enter below the Serial No. which is located on the rear of the cabinet. Retain this information for future reference.

Model No._____
Serial No. _____

Welcome to your TV/VCR owner's manual.

This manual has seven sections: Setting Up Your TV/VCR; Description of Controls; Basic Operations; Recording Options; Playing Options; Additional Features; and Information You May Need. The instructions explain all of the TV/VCR's features, which are listed below.

Features

- A-B Repeat Play
- Automatic Channel Setup
- Automatic Head Cleaner
- Automatic Operation Features
- Automatic Tracking Adjustment
- Blue Background
- Daylight-Savings Time
- Dew Sensor
- High Quality (HQ) System
- On-screen displays in English or Spanish
- On-screen Menu Programming, accessible with remote control or front panel buttons
- One-Touch Recording
- Real-Time Counter
- Remote Control
- Repeat Play
- S-VHS Quasi Play Back (SQPB)
- ShowGuard™ - Indefinite Timer Recording memory
- Sleep Timer
- SmartClock™
- Special Effects Playback: Forward and Reverse Searching; Still
- Timer Recording
- Wake Up Timer

Safety Precautions

Warning: To prevent fire or shock hazard, do not expose this equipment to rain or moisture.
Federal Communications Commission (FCC) Warning: Any unauthorized changes or modifications to this equipment void the user's authority to operate it.
This TV/VCR, equipped with a High Quality (HQ) system, is compatible with existing Video Home System (VHS) equipment.

Philips Consumer Electronics Company recommends that you use only video cassette tapes that are labeled with the VHS mark. The use of other tapes may result in poor picture quality and excessive deposits on the video heads, which may not be covered by the warranty if damage occurs.

Note to the Cable TV System Installer: This reminder is provided to call the Cable TV system installer's attention to Article 820-40 of the National Electrical Code, which provides guidelines for proper grounding – in particular, specifying that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as possible.

Declaration of Conformity

Model Number: CCB092AT
Trade Name: Philips
Responsible Party: Philips Consumer Electronics
P.O. Box 14810
Knoxville, TN 37914
(865) 521-4316

As an ENERGY STAR® Partner, Philips Consumer Electronics Company has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.
ENERGY STAR® is a U.S. registered mark.
Using products with the ENERGY STAR® label can save energy. Saving energy reduces air pollution and lowers utility bills.

SmartClock™, SmartLock™, and ShowGuard™ are trademarks of Philips Consumer Electronics Company.
Copyright 2000 Philips Consumer Electronics Company. All rights reserved.

Helpful Hints

- *Before doing anything else, record the TV/VCR's model and serial numbers in the spaces provided on page two. These numbers will help us assist you if you ever call for help.*
- *Your new product, its packaging, and this manual contain materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount that needs to be properly disposed.*
  Your product uses batteries that should not be thrown away when depleted but should be disposed of as small chemical waste.
  Please find out about the local regulations on disposal of your old product, batteries, manual, and packaging whenever you replace existing equipment.

Setting Up Your TV/VCR

Introduction 3
Table of Contents 4
Before Using the TV/VCR 5
Hooking Up the TV/VCR 6-8
Turning On the TV/VCR 9
Language Selection 10
Automatic Channel Setup 11-12
Setting the Clock 13-18
Daylight-Savings Time 19
Time Zone 20

Description of Controls

Front Panel 21
Rear Panel 22
Remote Control Buttons 23-24
Adjusting the Picture Controls 25-26
On-Screen Status Displays 27
Reminder 28

Basic Operations

Playing 29
Recording 30

Recording Options

One-Touch Recording 31
Rerecording (Tape Duplication) 32
Timer Recording 33-36
Defeat Recording 37

Playing Options

Repeat Play 38
A-B Repeat Play 39-40
Real-Time Counter Memory 41
Playback Options 42

Additional Features

Blue Background 43
Sleep Timer 44
Wake Up Timer 45
Volume Bar 46
Automatic Operation Features 47

Information You May Need

Specifications 48
Glossary 49
Helpful Hints 50-51
Limited Warranty 52
Index 53
Accessories 56

Putting Batteries in the Remote Control

1

Remove the battery compartment lid on the bottom of the remote control by sliding it in the direction of the arrow.

2

Place two AA batteries inside the battery compartment with their + and – ends aligned as indicated.

3

Replace the battery compartment lid.



Recording Prevention

Video cassette tapes have record tabs to ensure that recordings are not accidentally erased.

1

To prevent accidental recording, break off the tab with a screwdriver.

2

To record again, cover the hole with cellophane tape.



Using the Remote Control

- Point the remote control at the TV/VCR's remote sensor.
- Do not put objects between the remote control and the TV/VCR.

TV/VCR Maintenance

- In this TV/VCR, use only tapes with the VHS mark.
- Make sure any light adhesive stick-on notes are removed from the video cassette tape before putting the tape in the TV/VCR. Removable labels like these can jam the TV/VCR.
- Periodic maintenance is required to maintain your TV/VCR's excellent performance. This TV/VCR has an automatic head cleaning system. However, the video heads will eventually require cleaning or replacement. Only an authorized service center should perform this service.

Helpful Hints

- *The remote control and its batteries are supplied.*
- *Do not mix alkaline and manganese batteries.*
- *Do not mix old and new batteries.*

6 Hooking Up the TV/VCR

1

Hook up your TV/VCR using one of the connections shown.

A.

Hooking Up Your TV/VCR With a Cable Signal or Outdoor Antenna



B.

Hooking Up Your TV/VCR With a Cable Box

To view any channel, set the TV/VCR to the Cable Box output channel (channel 03 or 04). Then, select channels at the Cable Box.


Connect the Cable signal to the IN Jack on the Cable Box.
Connect an RF coaxial cable (75-ohm, not supplied) to the OUT Jack on the Cable Box and to the ANT(enna) Jack on the TV/VCR.
OUT
IN
RF coaxial cable (not supplied)
ANT.

C.

Hooking Up Your TV/VCR With an Indoor Antenna

To install a rod antenna (supplied), push the stem of the antenna into the antenna hole on the back of the TV/VCR. Connect the antenna wire to the ANT(enna) Jack on the back of the TV/VCR as shown. Extend the antenna and adjust its length, direction, and angle for the clearest picture.



2

Connect the AC cord to the AC 120V jack on the back of the TV/VCR. Plug the AC cord into an AC power outlet.



3

Before you turn on the TV/VCR, go to page nine.

Helpful Hint

- *Before connecting an antenna or cable signal to the ANT(enna) Jack, make sure the pin is not bent. If the pin is bent, straighten it as illustrated, then connect the antenna or cable signal to the ANT(enna) Jack.*



8 Hooking Up the TV/VCR (cont'd)

Mobile Connections

Usually, the supplied indoor rod antenna provides adequate reception. But when you want to watch TV outdoors or in a vehicle, use a mobile antenna (not supplied) or an indoor dipole antenna (not supplied) and a car battery cord (supplied) to get good reception.

1

Connect an antenna to the ANT(enna) jack. Refer to the instructions with your mobile antenna to make a connection similar to this one.



2

Make sure your vehicle has a 13.2-volt, negative ground electrical system. Connect one end of the car battery cord to the DC 13.2V jack on the back of the TV/VCR. Then connect the other end of the car battery cord to the cigarette lighter in your vehicle.



Fuse Replacement (Car Battery Cord)

If the TV/VCR does not have power when connected properly in your vehicle, you may need to replace the fuse in the car battery cord.

Use only a 5-amp, 250-volt, fast blow fuse, which is available at an electronics retailer.

1



To remove the old fuse, unscrew the red cap from the end of the cord. Place your fingers on the grooved part of the cap and turn the cap counter-clockwise.

2

When the cap is removed, the red cap and the silver tip will be loose. The fuse will be loose inside the end of the cord.

3



Remove the old fuse and insert a new fuse.

4



Replace the red cap and the silver tip. The fuse will tighten into place as you screw on the cap, turning the cap clockwise. (The end of the fuse will fit into the silver tip, which is in the center of the red cap when tightened.)

Helpful Hints

- *Do not watch TV while driving.*
- *Use only the supplied car battery cord. Using another cord could damage the TV/VCR.*
- *Make sure the cigarette lighter jack is free of ashes and other debris.*
- *Make sure you push the car battery cord's plug completely into the cigarette lighter.*
- *Always unplug the car battery cord from the cigarette lighter before you unplug it from the TV/VCR.*
- *You must disconnect the car battery cord from the TV/VCR before you can use standard electrical (AC) power.*
- *If you use the TV/VCR with the vehicle's engine off, recharge the vehicle's battery every four hours. Unplug the car battery cord from the cigarette lighter when you finish using the TV/VCR.*
- *When you use the TV/VCR with a car battery cord, noise may appear on the TV/VCR screen.*
- *Do not use this TV/VCR in high temperature conditions.*

Before you turn on the TV/VCR, make sure batteries are in the remote control and the TV/VCR is hooked up correctly.
The instructions on this page work only when you turn on the TV/VCR for the first time.



1

Press the POWER button. The TV/VCR will come on and the screen shown below will appear.

SELECT LANGUAGE

> ENGLISH ON

ESPAÑOL

SELECT ▲▼ OR
PRESS MENU TO CONTINUE

2

Press the PLAY/▲ button or the STOP/▼ button to select English or Spanish on-screen displays and menus.

3

Press the MENU button. The screen shown below will appear.

CONNECT ANTENNA OR CABLE
TO TVCR

THEN PRESS ►

TO END PRESS EXIT

4

Press the F.FWD/► button to begin automatic channel setup. The TV/VCR will memorize all available channels. When channels are set, CHANNELS ARE SET will appear on the screen briefly. Then the TV/VCR will go to the lowest channel programmed.
(If you try to set up channels when there is no antenna or cable connected to the TV/VCR, programming will appear to take place, but eventually a NO TV SIGNALS ... message will appear on the screen. Connect an antenna or cable to the ANT(enna) jack on the TV/VCR, then press the F.FWD/► button again. You may need to follow the steps on page 11 instead.)

5

Use the CH(annel) △/▽ button or the Number buttons on the remote control to select a TV/VCR channel. Use the VOL(ume) △/▽button to adjust the sound.

Helpful Hints

- *If you do not see any on-screen displays when you turn on the TV/VCR, check your hookups, then try again. If you still do not see any on-screen displays, follow the steps on pages 10-11 to select a language and set up channels.*
- *To skip step 2, press the MENU button. All on-screen displays will be in English. To skip step 4, press the STATUS/EXIT button. Channels will not be set up, and CHANNELS NOT SET will appear on the screen briefly.*
- *You cannot set up channels if you are using a Cable Box.*
- *Line Input mode will always be stored in the TV/VCR's memory as channel 00. When you select channel 00, A/V IN will appear on the screen briefly. Press the CH(annel) △/▽ button or the Number buttons to select another channel.*

10 Language Selection

Follow the steps below to change the language of the on-screen displays and menus.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to choose SELECT LANGUAGE. Then, press the F.FWD/► button.



4

Press the PLAY/▲ button or the STOP/▼ button to select ENGLISH or ESPAÑOL (Spanish).

5

Press the STATUS/EXIT button.

Helpful Hint

- *If you accidentally select Spanish and need English on-screen displays and menus:*
  1) Press the MENU button.
  2) Press the PLAY/▲ button or the STOP/▼ button to select PREPARACION, then press the F.FWD/► button.
  3) Press the PLAY/▲ button or the STOP/▼ button to select SELECCION IDIOMA, then press the F.FWD/► button.
  4) Press the PLAY/▲ button or the STOP/▼ button to select ENGLISH.
  5) Press the STATUS/EXIT button.

Although the TV/VCR may automatically memorize the channels you receive when you turn it on for the first time, you may set up channels again by following the steps below.

1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP, then press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select AUTO PROGRAMMING, then press the F.FWD/► button. AUTO CH PROGRAMMING ... will appear on the screen. The TV/VCR distinguishes between TV channels and cable channels automatically, and the TV/VCR will memorize its available channels.

4

Wait for a few minutes. When setup is complete, CHANNELS ARE SET will appear on the screen. Then the programming of the lowest channel number placed in the TV/VCR's memory will appear on the screen. Now, when you press the CH(annel) △/▽ button, you will scan only through channels you receive.



4 Wait for the TV/VCR to set up channels.

Helpful Hint

- *Line Input mode will always be stored in the TV/VCR's memory as channel 00. You cannot delete it.*

12 Automatic Channel Setup (cont'd)

Adding/Deleting Channels

1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select CHANNEL.



3

Press the CH(annel) △/▽ button to select the channel you want to add or delete.



4

Press the F.FWD/► button or the REW(ind)/◄ button to select SAVED (to add that channel) or DELETED (to delete that channel).

Repeat steps 3-4 to add or delete other channels.

5

Press the STATUS/EXIT button.

Programming of the channel you added or deleted will appear.



Helpful Hint

- *To review the channels memorized by the TV/VCR, follow these steps.*
  1) Press the MENU button.
  2) Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Press the F.FWD/► button.
  3) Press the PLAY/▲ button or the STOP/▼ button to select CH MEMORY REVIEW. Press the F.FWD/► button. A list of programmed channels will appear on the screen.
  4) If all the programmed channels don't fit on the screen, press the F.FWD/► button. If you do not press the F.FWD/► button within 10 seconds, the remaining channels will appear on the screen. (If there are no remaining channels, the previous menu will appear.) Or press the REW(ind)/◄ button to see the previous screen of channels.
  5) Press the STATUS/EXIT button once or twice.

There are three ways to set the clock: Manually, with Automatic PBS Channel Selection, or with Manual PBS Channel Selection. With manual clock setting, you tell the TV/VCR the current time. With Automatic or Manual PBS Channel Selection, the TV/VCR gets the time from your local PBS station.
If you use either Manual PBS Channel Selection or Automatic PBS Channel Selection, follow the steps on page 20 to have the TV/VCR maintain the clock according to your Time Zone.
Cable Box users must set the clock manually.
To set the clock manually, follow the steps on pages 13-14. To set the clock using Automatic PBS Channel Selection, follow the steps on pages 15-16. To set the clock using Manual PBS Channel Selection, follow the steps on pages 17-18.
Before you begin, make sure:

- The TV/VCR is hooked up and turned on.
- Channels are set up.
- You make each entry within 60 seconds of the previous entry.



Manual Clock Setting

1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/▶ button.



3

Press the PLAY/▲ button or the STOP/▼ button to select SET CLOCK. Then, press the F.FWD/▶ button.



Helpful Hints

- *Entries that do not match the TV/VCR's calendar will cause a question mark (?) to appear on the screen.*
- *To make corrections while you are setting the clock, press the CLEAR button until the space for the number you want to correct is flashing. Then enter the correct number.*

14 Setting the Clock (cont'd)

4

If ON appears beside AUTO CLOCK, press the F.FWD/► button so that OFF appears to the right of AUTO CLOCK, then press the MENU button. If OFF appears beside AUTO CLOCK, press the MENU button.



5

Press two Number buttons for the hour(s) and two Number buttons for the minute(s). Then press 1 for AM or 2 for PM. For example, for 9:30 PM, press 09, 30, 2.



6

Press two Number buttons for the month, two Number buttons for the day, and two Number buttons for the year. For example, for July 1, 2000, press 07, 01, 00. The day of the week will appear automatically.



7

Press the STATUS/EXIT button.



Automatic PBS Channel Selection

1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select SET CLOCK. Then, press the F.FWD/► button.



4

If ON appears beside AUTO CLOCK, press the MENU button. If OFF appears beside AUTO CLOCK, press the F.FWD/► button so that ON appears to the right of AUTO CLOCK, then press the MENU button.





16 Setting the Clock (cont'd)

5

Press the PLAY/▲ button or the STOP/▼ button to select SET PBS CH. AUTO. Then, press the F.FWD/► button.

```
SET AUTO CLOCK
   TIME     – – : – –
   DATE     – – / – – / – – – –
   NOW SEARCHING
TO END PRESS EXIT
```

6

NOW SEARCHING flashes on the TV/VCR screen.

7

When the TV/VCR finds the PBS channel, the time will appear on the screen. Press the STATUS/EXIT button.

```
SET AUTO CLOCK
   TIME     06 : 30 PM
   DATE     07 / 01 / 2000
            SATURDAY
TO END PRESS EXIT
```

- **If CANNOT FIND CLOCK DATA flashes on the TV/VCR screen, you will be prompted to turn off the TV/VCR. Turn off the TV/VCR.** Leave it off for several minutes. When you turn on the TV/VCR again, the clock will be set.

```
SET AUTO CLOCK
   TIME     – – : – –
   DATE     – – / – – / – – – –
CANNOT FIND CLOCK DATA
TO END PRESS EXIT
```

6 Wait for the TV/VCR to find the time.



Helpful Hints

- *To display the time on the TV/VCR screen, press the STATUS/EXIT button. Details are on page 27.*
- *You cannot use the AUTO CLOCK feature if you don't receive a PBS channel that carries a time signal in your area. Set the clock manually.*
- *Automatic clock setting is not possible with a mobile connection.*

Manual PBS Channel Selection



1

Press the MENU button.

```
> PRIM. SETUP        PRESS ►
  VCR PROGRAM
  VCR SETUP
  REMINDER
  BRIGHTNESS
  PICTURE
```

2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/► button.

```
        PRIMARY SETUP
> SELECT LANGUAGE
  AUTO PROGRAMMING
  CH MEMORY REVIEW
  VOLUME BAR          [ON]
  SET CLOCK

SELECT ▲▼ CHOOSE ►
TO  END  PRESS  EXIT
```

3

Press the PLAY/▲ button or the STOP/▼ button to select SET CLOCK. Then, press the F.FWD/► button.

```
          SET CLOCK
> AUTO CLOCK            [ON]
  SET MANUAL CLOCK
  DAYLIGHT SVG.TIME     [ON]
  SET TIME ZONE
   [AUTO]

TO CONTINUE PRESS MENU
SELECT ▲▼ CHOOSE ►
TO  END  PRESS  EXIT
```

4

If ON appears beside AUTO CLOCK, press the MENU button. If OFF appears beside AUTO CLOCK, press the F.FWD/► button so that ON appears to the right of AUTO CLOCK, then press the MENU button.

```
          AUTO CLOCK
  AUTO CLOCK USES
  PBS CHANNEL DATA
>  SET PBS CH.   AUTO
   SET PBS CH.   MANUAL

SELECT ▲▼ CHOOSE ►
TO  END  PRESS  EXIT
```

5

Press the PLAY/▲ button or the STOP/▼ button to select SET PBS CH. MANUAL. Then, press the F.FWD/► button.

AUTO CLOCK (PBS) CH 02

TIME –– : ––

DATE ––/––/––––

SELECT CHANNEL NUMBER
TO END PRESS EXIT

6

Use the Number buttons to select your PBS station.

AUTO CLOCK (PBS) CH 12

TIME –– : ––

DATE ––/––/––––

NOW SEARCHING

TO END PRESS EXIT

7

NOW SEARCHING flashes on the TV/VCR screen.

8

When the TV/VCR finds the clock data, the time will appear on the screen. Press the STATUS/EXIT button.

AUTO CLOCK (PBS) CH 12

TIME 06 : 30 PM

DATE 07 / 01 / 2000
SATURDAY

TO END PRESS EXIT

- **If CANNOT FIND CLOCK DATA flashes on the TV/VCR screen and you know another PBS channel, press the PLAY/▲ button or the STOP/▼ button to choose SELECT NEW PBS CH. Then, press the F.FWD/► button. Repeat step 6.**
- **If CANNOT FIND CLOCK DATA flashes on the TV/VCR screen and you do not know another channel, press the PLAY/▲ button or the STOP/▼ button to select SET PBS CH. AUTO. Then, press the F.FWD/► button.** The TV/VCR will search for the PBS channel automatically.
  - If the PBS channel is found, the time will appear on the screen.
  - If the PBS channel is not found, you will be prompted to turn off the TV/VCR. Leave it off for several minutes. When you turn on the TV/VCR again, the time will be set.

7 Wait for the TV/VCR to find the time.



Helpful Hints

- *If you have an Antenna hookup, you may select channels 2-69 at step 6. If you have a cable connection, you may select channels 1-125 at step 6. Details about available memorized channels are on page 12.*
- *To display the time on the TV/VCR screen, press the STATUS/EXIT button. Details are on page 27.*

When the Daylight-Savings Time feature is ON, the TV/VCR clock will automatically move forward one hour on the first Sunday in April and move back one hour on the last Sunday in October. To turn Daylight-Savings Time ON or OFF, follow the steps below.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select SET CLOCK. Then, press the F.FWD/► button.



4

Press the PLAY/▲ button or the STOP/▼ button to select DAYLIGHT SVG.TIME. Then, press the F.FWD/► button so that ON or OFF appears beside DAYLIGHT SVG. TIME (Daylight Savings Time).

5

Press the STATUS/EXIT button.

20 Time Zone

When you set the clock using AUTO CLOCK, specify your time zone.
The TV/VCR will maintain the clock according to your time zone.

1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select SET CLOCK. Then, press the F.FWD/► button.



4

Press the PLAY/▲ button or the STOP/▼ button to select SET TIME ZONE. Then, press the F.FWD/► button.

5

Press the PLAY/▲ button or the STOP/▼ button to select your time zone.

6

Press the MENU button, then press the STATUS/EXIT button.



Helpful Hints

- *If you select AUTO at step 5, the TV/VCR will set the clock according to the time zone data of the PBS station it finds.*
- *You cannot select SET TIME ZONE at step 4 if AUTO CLOCK is set to OFF.*

Cassette Compartment
Insert a video cassette tape here.

Wireless Remote Sensor
Receives a signal from your remote control so you can operate the TV/VCR from a distance.

REC(ord) Light
This light appears during a recording. It flashes slowly when the TV/VCR power is turned off to set a timer recording. It blinks rapidly when a recording is paused or when the power is off for a timer recording, but there is no tape in the TV/VCR. It will blink rapidly two minutes before a timer recording is set to begin if the TV/VCR power is on.

VIDEO Jack
Connect this jack to the video out jack of a camcorder or a VCR. *Details are on page 32.*

AUDIO Jack
Connect this jack to the audio out jack of a camcorder or a VCR. *Details are on page 32.*

POWER Button
Press to turn the power on or off.

STOP/EJECT Button
Press once to stop the tape. When playback is stopped, press to eject the tape. Press to select an item in the menu.

REW(ind) Button
When tape playback is stopped, press to rewind the tape at high speed. During playback, press to rewind the tape while the picture stays on the screen. Press to change a setting of a pop up menu item (for example, to adjust the BRIGHTNESS) or to return to the previous menu.

PLAY Button
Press to play a tape. *Details are on page 29.* Press to release Search or Still mode and return to normal playback. *Details are on page 42.* Press to select an item in the menu.

F.FWD Button
When tape playback is stopped, press to fast forward the tape at high speed. During playback, press to fast forward the tape while the picture stays on the screen. Press to change a setting of a menu item (for example, to adjust the BRIGHTNESS) or to advance to the next menu.

REC(ord)/OTR Button
Press once to start a recording. *Details are on page 30.* Press repeatedly to start a One-Touch Recording (an immediate timed recording, 30 minutes to eight hours long) of the channel you are watching. *Details are on page 31.*



CHANNEL ▲/▼ Buttons
Press to scan through the TV/VCR channels. During tape playback, press to adjust the tracking. *Details are on page 47.*
Press the CHANNEL ▲ button and the VOLUME ▼ button on the TV/VCR **at the same time** to display the pop up menu. Press again to remove the pop up menu.

VOLUME ▲/▼ Buttons
Press to adjust the sound level.
Press the CHANNEL ▲ button and the VOLUME ▼ button on the TV/VCR **at the same time** to display the pop up menu. Press again to remove the pop up menu.

EARPHONE Jack
Connect earphones (not supplied) here for personal listening.

Screen Cover
The TV/VCR screen is protected by a removable screen cover. If you want to remove the screen cover, slide the two tabs that hold the cover in place, then pull off the cover.

22 Rear Panel



ANT(enna) Jack
Connect your antenna or cable here.
Details are on pages six-eight.

DC 13.2V Jack
Connect the car battery cord here.
Details are on page eight.

AC 120V Jack
Connect the AC cord here. *Details are on page seven.*

Antenna Hole
Connect the stem of an indoor rod antenna here. *Details are on page seven.*

F.FWD/► Button
When tape playback is stopped, press to fast forward the tape at high speed. During tape playback, press to fast forward the tape while the picture stays on the screen. *Details are on page 42.* Press to change the setting of an item in the on-screen menu or press to proceed to the next menu.

SLEEP/WAKE UP Button
Press to set the Sleep Timer. *Details are on page 44.* Press to set the Wake Up Timer. *Details are on page 45.*

POWER Button
Press to turn on or off the TV/VCR.

PLAY/▲ Button
Press to play a tape. *Details are on page 29.* Press to release Search or Still mode and return to normal playback. *Details are on page 42.* Press to select an item in the menu.

CLEAR Button
Press to erase incorrect data when programming TV/VCR functions. Also, press to reset the real-time counter to 0:00:00. *Details are on page 41.*

Number Buttons
Use to select channels and to program TV/VCR functions (such as setting the clock).

- **Cable Users**

Enter channel numbers as a two-digit number for the quickest results. For example, to select channel 6, press 0,6. If you only press the Number 6 button, channel 6 will be selected after a brief delay. (There also may be a brief delay when you select channels 10, 11, and 12.) If you want to select channels 100 and above, enter channel numbers as a three-digit number. For example, to select channel 117, press 1, 1, 7.

- **Antenna Users**

Enter channel numbers as a two-digit number for the quickest results. You may only select channels 2-69. For example, to select channel 5, press 0,5. If you only press the Number 5 button, channel 5 will be selected after a brief delay.

SPEED Button
Press to select the recording speed (SP or SLP).

ALT. CH (Alternate Channel) Button
Press to return to the TV channel you were viewing immediately before switching to your current channel.

MUTE Button
Press to eliminate the TV/VCR's sound. Press again to return to the previous volume level.

VOL(ume) △/▽ Button
Press to adjust the sound level. If you press the VOL(ume) △/▽ button when the sound is muted, the sound will be restored.



24 Remote Control Buttons (cont'd)

STOP/▼ Button
Press to stop the tape. Press to select an item in the menu.

REW(ind)/◄ Button
When tape playback is stopped, press to rewind the tape at high speed. During tape playback, press to rewind the tape while the picture stays on the screen. *Details are on page 42.*
Press to change a setting of a pop up menu item or to return to a previous menu.

STATUS/EXIT Button
Press to see the status display. Press again to remove the status display. *Details are on page 27.* Press to exit the menu.

MENU Button
Press to display the pop up menu. You also may use the buttons on the front panel of the TV/VCR to access the pop up menu. *Details are on page 21.*

CH(annel) △/▽ Button
Press to scan through the TV/VCR's channels.



REC(ord)/OTR Button
Press once to start a recording. *Details are on page 30.* Or, press repeatedly to start a One-Touch Recording (an immediate timed recording, 30 minutes to eight hours long) of the channel you are watching. *Details are on page 31.*

MEMORY Button
Press to memorize a tape position at which the real-time counter was set to 0:00:00. *Details are on page 41.* Or, press to memorize the start and end positions on a tape when setting up A-B Repeat Play. *Details are on pages 39-40.*

TRACKING △/▽ Buttons
Press during tape playback to adjust the tracking. *Details are on page 47.*

PAUSE/STILL Button
During recording, press to temporarily stop the recording. Press again to resume recording. *Details are on page 30.* You cannot pause a One-Touch Recording.
During tape playback, press to freeze the picture (still). Each time you press the PAUSE/STILL button, the noise lines will change position on the screen. *Details are on page 42.*

Follow these steps to adjust the TV/VCR's brightness, picture, color, tint, and sharpness.

1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select the desired control (BRIGHTNESS, for example).

3

Press the REW(ind)/◄ button or the F.FWD/► button to adjust the picture control. (Refer to the chart on page 26.)

4

When you finish, press the STATUS/EXIT button.



Instructions continue on page 26.

Helpful Hints

- *The on-screen menus shown on page 26 will disappear if no adjustments are made within 60 seconds.*
- *The original settings will probably give you the best picture quality.*
- *To reset the picture controls to the original settings, press the MENU button, then press the PLAY/▲ button or the STOP/▼ button to select TV RESET, then press the F.FWD/► button. TV RESET COMPLETED will appear on the screen briefly.*

26 Adjusting the Picture Controls (cont'd)

	Decrease	Increase
BRIGHTNESS	decreased brightness	increased brightness
PICTURE	decreased contrast	increased contrast
COLOR	paler	more brilliant
TINT	more purple	more green
SHARPNESS	softer	clearer

Press the REW(ind)/◄ button to decrease a picture control. Press the F.FWD/► button to increase a picture control.





A status display will appear when you press the STATUS/EXIT button or certain function buttons. The contents of the status display will vary. To choose the status display mode, follow the steps below.

If you select STATUS ON, then select COUNTER ONLY OFF:

- Whenever you press the STOP/▼ button or the PLAY/▲ button, the status display will appear for five seconds. Portions of the status display also may appear when you press other function buttons.

If you select STATUS ON, then select COUNTER ONLY ON:

- Whenever you press the PLAY/▲ button, the status display will appear for five seconds. After five seconds, only the counter will remain on the screen. Portions of the status display also may appear when you press other function buttons.

If you select STATUS OFF:

- The status display will not appear when you press function buttons. You must press the STATUS/EXIT button to see the status display.



1

Press the MENU button.

2

Press the PLAY/▲ button or the STOP/▼ button to select VCR SETUP, then press the F.FWD/► button.

3

Press the PLAY/▲ button or the STOP/▼ button to select ON-SCREEN MODE, then press the F.FWD/► button.

4

Press the PLAY/▲ button or the STOP/▼ button to select STATUS, then press the F.FWD/► button so that ON or OFF appears beside STATUS.



5

If you set STATUS to OFF, go to step 6. If you set STATUS to ON, press the PLAY/▲ button or the STOP/▼ button to select COUNTER ONLY, then press the F.FWD/► button so that ON or OFF appears beside it.

6

Press the STATUS/EXIT button.

28 Reminder

The channel number will remain on the screen at all times when you set REMINDER to ON.
Set REMINDER to ON or OFF by following the steps below.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select REMINDER.



3

Press the REW(ind)/◄ button or the F.FWD/► button to select ON or OFF. Each press of the REW(ind)/◄ button or the F.FWD/► button turns REMINDER ON or OFF.



4

Press the STATUS/EXIT button.

Follow the steps below to play a tape.

1

Insert a tape in the TV/VCR. The power will come on. If the tape's record tab has been removed, playback should start automatically.

2

If playback does not start automatically, press the PLAY/▲ button to start playback.

3

Press the STOP/▼ button on the remote control or the STOP/EJECT button on the TV/VCR once to stop playback.

4

Press the REW(ind)/◄ button to rewind the tape.

5

When the tape has finished rewinding, press the STOP/EJECT button on the TV/VCR to remove the tape.

1 Insert a tape in the TV/VCR.

5 Press the STOP/EJECT button on the TV/VCR.



S-VHS Quasi Play Back (SQPB)

This unit has a SQPB function that allows you to view a tape recorded in S-VHS format. A tape recorded in S-VHS format will play the same as a tape recorded in normal format. This unit detects whether the tape is recorded in S-VHS format or in nor-mal format.

Helpful Hints

- *If the tape you want to play is already in the TV/VCR, turn on the TV/VCR power, then press the PLAY/▲ button.*
- *Playback features and options are on pages 38-42.*
- *When you play a tape recorded in S-VHS format on this unit, you can not get the high resolution that would be available on an S-VHS VCR. Noise lines (black and white streaks) may appear on the picture.*

30 Recording

Read and follow the steps below to record a TV program.

1

Place a tape with its record tab intact (see page five) in the TV/VCR. The power will come on. **Or, if the tape is already in the TV/VCR, press the POWER button to turn on the TV/VCR, if necessary.**

2

Press the SPEED button until the desired tape speed appears on the TV/VCR screen. *Details about tape speed are given below.*

3

Use the CH(annel) △/▽ button or the Number buttons to select the channel to be recorded. (Channels cannot be changed during recording.)

4

Press the REC(ord)/OTR button once to start recording. The RECORD light will glow.

- If there is not a tape in the TV/VCR, NO CASSETTE flashes on the screen briefly.
- If the tape does not have a record tab, PROTECTED CASSETTE CANNOT RECORD flashes on the screen briefly. The TV/VCR will eject the tape. Insert another tape.

5

To pause the recording (for example, during commercials), press the PAUSE/STILL button. The RECORD light will flash. **To resume recording, press the PAUSE/STILL button again or the REC(ord)/OTR button.** The RECORD light will glow.

6

To stop recording, press the STOP/▼ button.



Tape Speeds

This chart shows the recording/playback time for three types of video cassettes (T160, T120, and T60). There are three playback speeds: SP, LP, and SLP. During playback, the VCR selects the tape speed automatically. When recording, you can change the tape speed using the SPEED button. You cannot record in LP speed.

Tape Speed	Cassette type / Playback Time T160	T120	T60
SP(Standard Play)	2 hrs. 40 mins.	2 hrs.	1 hr.
LP(Long Play) (playback only)	5 hrs. 20 mins.	4 hrs.	2 hrs.
SLP(Super Long Play)	8 hrs.	6 hrs.	3 hrs.

Helpful Hints

- *You cannot record one channel while watching another.*
- *Recording options are on pages 31-37.*
- *You cannot record if DEFEAT RECORDING is set to ON. (REC DEFEATED will flash on the screen.) Details are on page 37.*
- *If you pause a recording for more than five minutes, the TV/VCR will switch to Stop mode automatically to protect the video cassette tape from damage.*
- *You can change the tape speed with the SPEED button while a recording is in progress, but some distortion may appear on the tape.*

The One-Touch Recording (OTR) function allows you to program an immediate timed recording from 30 minutes to eight hours long without setting the timer.

Before you begin, make sure:

- Channels are set up.
- There is a tape in the TV/VCR. The record tab must be intact.

1

Use the CH(annel) △/▽ button or the Number buttons to select the channel you want to record.

2

Press the SPEED button until the desired recording speed (SP or SLP) appears on the screen. *Details are on page 30.*

3

Press the REC(ord)/OTR button repeatedly until the desired recording length appears in the upper right corner of the screen. Recording will begin immediately. The RECORD light will appear.



4

To stop an OTR before recording is finished, press the STOP/EJECT button on the TV/VCR.
Or, press the REC(ord)/OTR button, then press the CLEAR button, then press the STOP/▼ button on the remote control.

4 Press the STOP/EJECT button on the TV/VCR to stop the OTR.



Helpful Hints

- *To check the time remaining for an OTR after the OTR has been set, press the STATUS/EXIT button.*
- *To change the recording length while an OTR is in progress, press the REC(ord)/OTR button until the desired recording length appears on the screen.*
- *You can not pause an OTR.*
- *To cancel an OTR but continue recording, press the REC(ord)/OTR button, then press the CLEAR button.*
- *You cannot record if DEFEAT RECORDING is set to ON. Details are on page 37.*
- *You can change the tape speed with the SPEED button while a recording is in progress, but some distortion may appear on the tape.*

32 Rerecording (Tape Duplication)



1

Make the connections shown above, using audio and video cables. Connect the source unit (VCR or camcorder) to a power source after connections are made.

2

The source unit will play your tape. **Insert a prerecorded tape in the source unit.** If playback begins, press the STOP button on the unit.

3

The TV/VCR will record your tape. **Insert a blank tape in the TV/VCR.** Make sure the tape's record tab is intact. The TV/VCR power will turn on automatically.

4

Point the TV/VCR remote control at the TV/VCR. Press Number buttons 0, 0 so that A/V IN appears on the screen.

5

Point the TV/VCR remote control at the TV/VCR. Press the SPEED button until the desired tape speed (SP or SLP) appears on the screen.

6

Press the PLAY button on the source unit and the REC(ord)/OTR button on your TV/VCR at the same time. Copying will begin.

7

To stop copying, press the STOP/EJECT button on the TV/VCR, then stop the tape on the source unit (VCR or camcorder).

Helpful Hints

- *Unauthorized recording of copyrighted television programs, video tapes, or other materials may infringe on the rights of copyright owners and violate copyright laws.*
- *Different brands of equipment may operate differently.*
- *Make sure all connections are secure. Otherwise, you may not record both picture and sound.*
- *Audio and video cables are not included.*

Follow the steps below to program the TV/VCR to record TV programs while you're away from home. The TV/VCR will turn itself on, record, and turn itself off automatically. Before you begin, make sure:

- The clock is set. If not, CLOCK MUST BE SET appears, followed by the SET CLOCK menu.
- Channels are set up.
- There is a tape in the TV/VCR. (Make sure the tape's record tab is intact and the tape is long enough to record the program.)

Complete each step within 60 seconds of completing the previous step. If you don't, you may start again at step 1.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select VCR PROGRAM, then press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select a ONCE, DAILY, OR WEEKLY recording. Then, press the F.FWD/► button.

- **ONCE:** The TV/VCR will record a TV program on any day you choose, up to 12 months away.
- **DAILY:** The TV/VCR will record every day from Monday to Friday – starting at the same time and recording the same channel for the same length of time.
- **WEEKLY:** The TV/VCR will record the same channel on the same day, at the same time, and for the same length of time every week.

Daily Recording (example)



Instructions continue on page 34.

Helpful Hints

- *With ShowGuard, you don't have to worry about losing your timer recordings. If the power fails, programmed timer recordings will be restored when the clock is reset. (The clock will reset itself automatically if you are using the AUTO CLOCK feature. Details are on pages 15-18. If you are not using the AUTO CLOCK feature, reset the clock manually. Details are on pages 13-14.) The timer recording will not occur only if the timer recording was scheduled to take place during the power failure.*
- *You cannot set a timer recording if DEFEAT RECORDING is set to ON. Details are on page 37.*

34 Timer Recording (cont'd)

4

Use the Number buttons (1-8) to select a position in which to store the timer recording. Flashing numbers indicate an open position (one in which a timer recording has not been stored yet).

NOTE: If you select a number that already has been used to store a timer recording, PREVIOUSLY SET PROGRAM will appear on the screen for a few seconds. Then information about the program in that position will appear on the screen. If this happens, press the STATUS/EXIT button. Then use the Number buttons to select another position.

5

Use the Number buttons to enter the channel of the TV program you want to record.

- If you are recording from line input, press 0, 0. A/V IN will appear on the screen.
- If you are recording using a Cable Box, enter the Cable Box output channel (03 or 04). Be sure to select the channel of the TV program at the Cable Box and leave the Cable Box on for the timer recording.

```
ONE TIME PROGRAM

  PROGRAM  1
  CHANNEL  – – –


TO CORRECT PRESS CLEAR
TO END PRESS EXIT
```

6

Press two Number buttons for the hour(s) you want the recording to begin. Press two Number buttons for the minute(s) you want the recording to begin. Press 1 for AM or 2 for PM. For example, for 9:30 PM, press 09, 30, 2.

```
ONE TIME PROGRAM
  PROGRAM  1

  CHANNEL  10
  TIME ON  – – : – –


TO CORRECT PRESS CLEAR
TO END PRESS EXIT
```

7

Follow the instructions in step 6 to set the recording's stop time. (AM or PM will be set automatically.)

```
ONE TIME PROGRAM
  PROGRAM  1

  CHANNEL  10
  TIME ON  09:30 PM
  TIME OFF – – : – –


TO CORRECT PRESS CLEAR
TO END PRESS EXIT
```

4-7



Helpful Hints

- *If the numbers entered do not match the TV/VCR's clock or calendar, the entry will be rejected and a question mark will appear on the screen.*
- *To make corrections while you are programming a timer recording, press the CLEAR button until the cursor is flashing on the item you want to change. Then enter the correct information.*

8

Press the Number 1 button to record in SP speed or press the Number 2 button to record in SLP speed. *Details about tape speed are on page 30.* You cannot use the SPEED button at this time.

```
ONE TIME PROGRAM

  PROGRAM  1

  CHANNEL  10
  TIME ON  09:30 PM
  TIME OFF 11:00 PM
  REC SPEED SLP
    SP=1  SLP=2

TO CORRECT PRESS CLEAR
TO END PRESS EXIT
```

9

Press two Number buttons for the month and two Number buttons for the day you want the program to record. For example, for July 10, 2000, press 07, 10. The day of the week and the year will be displayed automatically. (You cannot program the TV/VCR to record more than one year in advance.)

```
ONE TIME PROGRAM

  PROGRAM  1

  CHANNEL  10
  TIME ON  09:30 PM
  TIME OFF 11:00 PM
  REC SPEED SLP
  START DATE 07/10/2000
             MONDAY

TO CORRECT PRESS CLEAR
TO END PRESS EXIT
```

10

Press the STATUS/EXIT button. PROGRAM WAS COMPLETED PLEASE TURN OFF FOR TIMER RECORDING will appear on the screen.

- If there is not a tape in the TV/VCR, PLEASE INSERT CASSETTE also appears on the screen.
- If there is a tape without a record tab in the TV/VCR, PLEASE REMOVE CASSETTE also appears on the screen. If this happens, insert a different tape.
- If PROGRAM NOT COMPLETED appears, start again at step 1.

11

Press the POWER button to turn off the TV/VCR power. The RECORD light will flash slowly. If you forget to turn off the TV/VCR, PLEASE TURN OFF FOR TIMER RECORDING appears on the TV/VCR screen two minutes before a timer recording is scheduled to begin.



Turn off the TV/VCR for the recording. Insert a tape in the TV/VCR. Leave the Cable Box/DBS on (if applicable).

Helpful Hints

- *PROGRAM NOT COMPLETED / CLASH may appear on the screen when you finish setting a timer recording. This means that the timer recording you just programmed and another timer recording overlap, and thus the current timer recording will not be carried out.*
- *To stop a started timer recording, press the STOP/EJECT button on the TV/VCR.*

Please see page 50 for more Helpful Hints.

Checking or Clearing Timer Recordings



1

With the TV/VCR on, press the MENU button.

2

Press the PLAY/▲ button or the STOP/▼ button to select VCR PROGRAM, then press the F.FWD/► button.

3

Press the PLAY/▲ button or the STOP/▼ button to select PROGRAM REVIEW, then press the F.FWD/► button. The timer recording information for the program in the lowest numbered position will appear on the screen. If no timer recordings are programmed, nothing will happen when you select PROGRAM REVIEW and press the F.FWD/► button.

4

Press the F.FWD/► button to display information about the next programmed timer recording. (If you do not press a button within 10 seconds, information about the next programmed timer recording will appear.) This will continue until all positions have been displayed. Then, the menu will disappear. You can exit the Program Review at any time by pressing the STATUS/EXIT button.

5

To cancel the timer recording displayed, press the CLEAR button. Either the display will disappear or information about other timer recordings will appear. If you do not press any other buttons, the display will disappear after all timer recordings have been displayed.

6

Repeat steps 1 - 4 to make sure you have cleared the correct position.

Helpful Hint

- *With ShowGuard, you don't have to worry about losing your timer recordings. If the power fails, programmed timer recordings will be restored when the clock is reset. (The clock will reset itself automatically if you are using the AUTO CLOCK feature. Details are on pages 15-18. If you are not using the AUTO CLOCK feature, reset the clock manually. Details are on pages 13-14.) The timer recording will not occur only if the timer recording was scheduled to take place during the power failure.*

Follow the steps below to prevent accidental recording.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select VCR SETUP, then press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select DEFEAT RECORDING, then press the F.FWD/► button so that ON appears beside DEFEAT RECORDING.



4

Press the STATUS/EXIT button.

5

Now, REC DEFEATED will flash on the screen when you press the REC(ord)/OTR button.



Helpful Hints

- *If you set DEFEAT RECORDING to ON after a timer recording has been set, the timer recording will not occur.*
- *You can not program a timer recording if DEFEAT RECORDING is set to ON.*
- *To set DEFEAT RECORDING to OFF, repeat steps 1-2 above. At step 3, press the PLAY/▲ button or the STOP/▼ button to select DEFEAT RECORDING, then press the F.FWD/► button so that OFF appears beside DEFEAT RECORDING. Press the STATUS/EXIT button.*

38 Repeat Play

Follow the steps below to program the TV/VCR to play a tape over and over.



1

Press the MENU button.

```
> PRIM. SETUP        PRESS ►
  VCR PROGRAM
  VCR SETUP
  REMINDER
  BRIGHTNESS
  PICTURE
```

2

Press the PLAY/▲ button or the STOP/▼ button to select VCR SETUP, then press the F.FWD/► button.

```
            VCR SETUP

  > ONE TIME PLAY       [ON]
    REPEAT PLAY
    ON-SCREEN MODE
    DEFEAT RECORDING [OFF]
    BLUE BACKGROUND  [ON]

  SELECT ▲▼ CHOOSE ►
  TO END PRESS EXIT
```

3

Press the PLAY/▲ button or the STOP/▼ button to select REPEAT PLAY, then press the F.FWD/► button so that ON appears beside REPEAT PLAY.

```
            VCR SETUP

    ONE TIME PLAY
  > REPEAT PLAY         [ON]
    ON-SCREEN MODE
    DEFEAT RECORDING [OFF]
    BLUE BACKGROUND  [ON]

  SELECT ▲▼ CHOOSE ►
  TO END PRESS EXIT
```

4

Press the STATUS/EXIT button. Now, when a tape has finished playing, the TV/VCR will rewind it and start playback again. (TV programming will appear while the tape is rewinding.)

Helpful Hints

- *The TV/VCR will stay in Repeat Play mode until you set ONE TIME PLAY to ON, even if the TV/VCR is turned off. To set ONE TIME PLAY to ON, follow steps 1-2 above. Then, press the PLAY/▲ button or the STOP/▼ button to select ONE TIME PLAY. Press the F.FWD/► button so that ON appears beside ONE TIME PLAY. Then, press the STATUS/EXIT button.*
- *The real-time counter memory will not function during Repeat Play mode.*

Follow the steps below to program the TV/VCR to play the material between two specified points (A and B) on a tape over and over again.

1

Insert a tape in the TV/VCR.

2

Press the MENU button.



3

Press the PLAY/▲ button or the STOP/▼ button to select VCR SETUP, then press the F.FWD/► button.



4

Press the PLAY/▲ button or the STOP/▼ button to select REPEAT PLAY.



5

Press the F.FWD/► button repeatedly so that A-B appears beside REPEAT PLAY.



Instructions continue on page 40.

1 Insert a tape in the TV/VCR.



Helpful Hints

- *To cancel A-B Repeat Play, set ONE TIME PLAY to ON. To set ONE TIME PLAY to ON, follow steps 2-3 above. Then, press the PLAY/▲ button or the STOP/▼ button to select ONE TIME PLAY. Press the F.FWD/► button so that ON appears beside ONE TIME PLAY. Then, press the STATUS/EXIT button.*
- *The end position (B) must be later on the tape than the start position (A).*

6

Press the STATUS/EXIT button to remove the menu. A-B REPEAT will appear on the screen. Beneath it, the letter A will flash beside the real-time counter.



7

Play, fast forward, or rewind the tape to the position at which you want to begin playback. Stop the tape, then press the MEMORY button to set the start position (A). The flashing A will become a flashing B.



8

Play or fast forward the tape to the position at which you want playback to end. Stop the tape, then press the MEMORY button to set the end position (B).

- The length of time between the start position (A) and the end position (B) must be at least three minutes.

9

The TV/VCR will immediately rewind the tape to the start position (A) and repeat playback to the end position (B) over and over.
(TV programming will appear while the tape is rewinding.)



Helpful Hints

- *The counter cannot be memorized or reset when you are using this feature.*
- *A-B Repeat Play will be cancelled if you eject the tape or press the REC(ord)/OTR button.*
- *A-B REPEAT will not appear on the screen at step 6 if a tape is not in the TV/VCR. NO CASSETTE will flash on the screen briefly.*
- *You cannot rewind or fast forward beyond points A or B when you are using this feature.*
- *A-B Repeat Play will be retained if you turn off the TV/VCR power.*

Follow the steps below to reset the real-time counter to zero at a tape location you want to refer to later.



1

Play, fast forward, or rewind a tape to the location that you would like to refer to later. Stop the tape.

2

Press the STATUS/EXIT button. The real-time counter will appear on the screen.



3

While the counter remains on the screen, press the CLEAR button to reset the real-time counter to zero.



4

While the counter remains on the screen, press the MEMORY button so that M appears on the screen. To erase a real-time counter memory, press the MEMORY button so that the M disappears from the screen.

5

To go to a tape location where the real-time counter was reset to zero, press the REW(ind)/◄ button or the F.FWD/► button when playback is stopped. When the tape reaches the point at which the counter was set to zero, the tape will stop. Press the PLAY/▲ button to watch the tape.

Helpful Hints

- *The real-time counter memory will not function during Repeat Play mode. Details are on page 38.*
- *You may only set one real-time counter memory at a time. If you set the real-time counter to zero at a second location, the previous real-time counter to zero setting will be lost.*

Forward and Reverse Searching (SP/LP/SLP)

1

During tape playback, press and release the F.FWD/► button or the REW(ind)/◄ button. A fast forward or reverse picture search will begin.

2

To return to normal playback, press the PLAY/▲ button.

Super High Speed Searching (LP/SLP)

1

During tape playback, press the F.FWD/► button or the REW(ind)/◄ button, then press again. The TV/VCR will now search in super high speed.

2

To return to normal playback, press the PLAY/▲ button.

Viewing a Still Picture

1

During tape playback, press the PAUSE/STILL button. A still picture will appear on the screen. The noise lines will move each time you press the PAUSE/STILL button.

2

To release the still picture and return to normal playback, press the PLAY/▲ button.



Helpful Hints

- *Still mode will automatically switch to Stop mode after five minutes to protect the TV/VCR and the tape from damage.*
- *SP/LP/SLP means this feature will work with tapes recorded in Standard Play, Long Play, or Super Long Play. For details about tape speed, see page 30.*
- *LP/SLP means this feature will work with tapes recorded in Long Play and Super Long Play. For details on tape speed, see page 30.*
- *During forward and reverse searching, horizontal noise bars will appear on the TV/VCR screen.*
- *Tapes recorded in SLP speed will have the clearest picture during forward and reverse searching and Still mode.*

If you want the TV screen to be solid blue when a weak signal is received, set BLUE BACKGROUND to ON. The screen will be blue and the sound will be muted. Or, if you want to receive the weak signal, set BLUE BACKGROUND to OFF. When you select a channel that is receiving a weak signal, you will see and hear the static in the TV programming.
To set BLUE BACKGROUND to ON or OFF, follow the steps below.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select VCR SETUP, then press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select BLUE BACKGROUND. Then, press the F.FWD/► button repeatedly so that OFF (or ON) appears beside BLUE BACKGROUND.



4

Press the STATUS/EXIT button.

Helpful Hint

- *A blue screen may appear briefly between channel changes if BLUE BACKGROUND is set to ON. To avoid seeing the brief blue screen, set BLUE BACKGROUND to OFF.*

44 Sleep Timer

Use the sleep timer to program the TV/VCR to shut off in a certain amount of time.

1

Press the SLEEP/WAKE UP button.



2

Press the PLAY/▲ button or the STOP/▼ button to select SLEEP. Then press the REW(ind)/◄ button or the F.FWD/► button to select 30 MIN(utes), 60 MIN(utes), 90 MIN(utes), or 120 MIN(utes). (You can not set the sleep timer during a recording.)



3

Press the STATUS/EXIT button. The TV/VCR will shut itself off after the specified amount of time.
One minute before the TV/VCR shuts itself off, the seconds will count down on the screen.
GOOD NIGHT appears on the TV/VCR screen 10 seconds before the TV/VCR shuts itself off.



Helpful Hints

- *To cancel the sleep timer, press the SLEEP/WAKE UP button. Press the PLAY/▲ button or the STOP/▼ button to select SLEEP, then press the REW(ind)/◄ button or the F.FWD/► button to select OFF. Press the STATUS/EXIT button.*
- *To see how much time remains before the TV/VCR shuts itself off, press the SLEEP/WAKE UP button once. To remove the display, press the STATUS/EXIT button.*

The Wake Up Timer turns on the TV/VCR automatically at a specified time within the next 24 hours. You may set the TV/VCR to turn on at a TV channel (the channel at which the TV/VCR was set last) or with VCR playback. To set the Wake Up Timer, follow the steps below. Before you begin:

- Make sure the clock is set. If the clock has never been set, CLOCK MUST BE SET will appear on the screen after you select WAKE UP at step 2. Then the SET CLOCK menu will appear.
- Make sure a tape is in the TV/VCR if you want the TV/VCR to start tape playback at the specified time.
- Make sure no timer recordings are set for the time at which you want the TV/VCR power to come on.



1

Press the SLEEP/WAKE UP button.



2

Press the PLAY/▲ button or the STOP/▼ button to select WAKE UP. Then, press the REW(ind)/◀ button or the F.FWD/▶ button to select TV ON or VCR ON.



3

Press the PLAY/▲ button or the STOP/▼ button to select ON-TIME. Then, press the REW(ind)/◀ button or the F.FWD/▶ button to select your desired wake up time. Each press of the REW(ind)/◀ button or the F.FWD/▶ button will increase (or decrease) the time by 10 minutes.



4

Press the STATUS/EXIT button.

5

Press the POWER button to turn off the TV/VCR. The TV/VCR will turn itself on at the specified time.

Helpful Hint

- *To cancel the Wake Up Timer, press the SLEEP/WAKE UP button. Press the PLAY/▲ button or the STOP/▼ button to select WAKE UP. Then, press the REW(ind)/◀ button or the F.FWD/▶ button to select OFF. Press the STATUS/EXIT button.*

46 Volume Bar

Usually, the volume bar appears when you press the VOL(ume) △/▽ button. If you do not need it, set the VOLUME BAR to OFF. For example, when you watch a program that is being broadcast with closed captions, you may choose to set the VOLUME BAR to OFF so the captions can remain on the screen. The captions will remain on the screen even when you press the VOL(ume) △/▽ button or the MUTE button.



1

Press the MENU button.



2

Press the PLAY/▲ button or the STOP/▼ button to select PRIM. SETUP. Then, press the F.FWD/► button.



3

Press the PLAY/▲ button or the STOP/▼ button to select VOLUME BAR, then press the F.FWD/► button. Each press of the F.FWD/► button will turn the VOLUME BAR ON or OFF.

4

Press the STATUS/EXIT button.

The following playback features will always operate.

Automatic Playback

When you put a tape in the TV/VCR, the power will come on automatically. If the tape's record tab is missing, playback will begin. If a timer recording is set, the power will not come on automatically when you insert a tape with the record tab intact. If a timer recording is set and the TV/VCR power is off, the TV/VCR will eject the tape if the record tab is missing.

Automatic Rewind, Eject, Off

When a tape is played, fast forwarded, or recorded to its end, the TV/VCR will rewind the tape, stop, turn itself off, and eject the tape. If a real-time counter memory is set, the TV/VCR may only rewind the tape to the point at which the real-time counter is set to zero. The TV/VCR will not turn itself off or eject the tape.

Memory Rewind, Power Off

When the POWER button is pressed while the TV/VCR is rewinding a tape, REW → POWER OFF will appear on the screen. The TV/VCR will turn itself off when the tape has finished rewinding. If a real-time counter memory is set, the TV/VCR may only rewind the tape to the point at which the counter was set to zero, then turn itself off.

Tape Eject

A tape can be ejected with the TV/VCR power on or off (but the TV/VCR must be plugged in). If a timer recording is programmed, a tape can not be ejected when the power is off. Turn on the TV/VCR power, then eject the tape. Be sure to insert a tape and turn off the TV/VCR power for the timer recording.

Automatic Tracking Adjustment

The TV/VCR automatically adjusts the tracking to give you the best possible picture quality. With some recordings, however, you may get a better picture using the manual tracking controls (see below).

Manual Tracking

To adjust the tracking manually, press the CHANNEL ▲/▼ buttons on the TV/VCR or the TRACKING △/▽ buttons on the remote control.
Tracking returns to Automatic Tracking Adjustment when a tape is inserted or when the STOP/▼ button is pressed.

Before Tracking Adjustment



After Tracking Adjustment

48 Specifications

General

CRT: 9-inch in line gun
Television system: NTSC-M
Video Heads: Two heads
Tape width: 1/2 inch (12.65 mm)
Tape speed
SP: 33.35 mm/sec.
LP: 16.67 mm/sec.
SLP: 11.12 mm/sec.
Operating Temperature: 41˚F (5˚C) to 104˚F (40˚C)
Relative Humidity: 10% to 75%
Power requirement: AC 120V/DC 13.2V, 60Hz
Power consumption: 60W (AC/DC)
Sound output: 0.8W
Dimensions:
13" (H) x 12-1/8" (W) x 12-15/16" (D)
330mm x 308mm x 329mm
Weight: 18.8 lbs (8.5 kg)

Tuner Broadcast Channels

VHF 2-13, UHF 14-69

Cable TV Channels

1-125

Terminals

Antenna In: VHF/UHF 75 ohms unbalanced
Video In: RCA connector
Audio In: RCA connector
Earphone: 3.5 mm CES

Electrical Specifications

Video input level: 0.5~2.0Vp-p
Audio input level: -10dBv
Video S/N ratio
SP: More than 42dBµ
Audio S/N ratio
SP: More than 38dB

Designs and specifications are subject to change without notice and without our legal obligation.

AUDIO Jack: jack located on the front of the TV/VCR which is used to record audio from another source.

Automatic Channel Setup: process in which the TV/VCR scans all available channels and places the ones you receive in its memory. Then, when you push the CH(annel) ▲/▼ buttons, you only scan through channels you receive.

Bands: settings that allow you to tune channels.

- **Antenna** – VHF (very high frequency; channels 2-13) and UHF (ultra high frequency; channels 14-69).
- **Cable** – all standard channels can be received without a Cable Box.

Brightness: adjusting increases or decreases the brightness of the color on the screen.

Color: adjusting pales or brightens the TV/VCR color.

Dubbing: copying a tape using a VCR.

HQ: high quality; a feature in the TV/VCR circuitry which provides enhanced picture detail.

Line Input: The channel to which you set your TV/VCR during dubbing. The line input channel is always channel 00 (A/V IN).

Mode: a TV/VCR operation.

OTR: One-Touch Recording; a timed recording that starts immediately and records for 30 minutes to eight hours, whichever you specify.

Picture: adjusting increases or decreases the contrast of the picture on the screen.

Sharpness: adjusting softens or clarifies the picture on the screen.

Tape Speeds: how fast the tape travels during playback or recording.

- **SP** (standard play) – fastest tape speed (recording time for a T120 tape is approximately two hours); best picture quality.
- **LP** (long play) – average tape speed; playback only.
- **SLP** (super long play) – slowest tape speed (recording time for a T120 tape is approximately six hours).

Tint: adjusting changes the tints of the picture on the TV/VCR from purple to green.

VIDEO Jack: jack located on the front of the TV/VCR which is used to record video from another source.

50 Helpful Hints

If you are having problems with your product, check this list of problems and possible solutions before requesting service. You may be able to solve the problem yourself.
If you need to call a customer service representative, please know the model number and serial number of your product before you call. This information is displayed on the back of the product. Also, please take a moment to identify the problem you are having, and be prepared to explain this to the representative. If you believe the representative will need to help you with operations, please stay near the product. Our representatives will be happy to assist you.

Location

For safe operation and satisfactory performance of your TV/VCR, remember the following:

- Shield it from direct sunlight and keep it away from sources of intense heat.
- Avoid dusty or humid places.
- Avoid places with insufficient ventilation. Do not block the ventilation openings at the top and bottom of the TV/VCR. Do not place the TV/VCR on a carpet, as this will block the ventilation openings.
- Avoid locations subject to strong vibrations.
- Do not place the TV/VCR near strong magnetic fields.
- Do not move the TV/VCR from a cold place to a hot place, or vice versa.
- Do not use this TV/VCR under high temperature conditions.

Electrical Shock and Fire Hazards

- Do not handle the power cord with wet hands.
- Do not pull the power cord when disconnecting the TV/VCR from the AC (alternating current) wall outlet. Grasp it by the plug.
- If water is spilled on the TV/VCR, unplug the power cord immediately and take the TV/VCR to an authorized service center.
- Do not put your fingers or objects into the TV/VCR cassette compartment.
- Do not place anything on top of the TV/VCR.

Dew Warning/Display (Moisture Condensation)

- The TV/VCR has a sensor that detects moisture condensation. Moisture may condense inside the TV/VCR when it is moved from a cold place to a warm place, after heating a cold room, or under conditions of high humidity. If excessive moisture is present inside the TV/VCR, "DEW PROTECTION PLEASE WAIT" appears on the screen. While "DEW PROTECTION PLEASE WAIT" appears, a safety device prevents the VCR from operating until moisture is gone. When "DEW PROTECTION PLEASE WAIT" appears on the screen, keep the TV/VCR power on, but do not try to play a tape. Allow at least two hours for the TV/VCR to dry. "DEW PROTECTION PLEASE WAIT" may appear for up to one hour after moisture is gone. During this time, you can not insert a cassette.

TV/VCR will not perform a timer recording.

- Make sure the recording start and stop times are set correctly. *Details are on pages 33-36.* Midnight is 12 a.m. Noon is 12 p.m.
- Make sure the TV/VCR power is off.
- Make sure the clock is set. *Details are on pages 13-18.*
- Make sure there is a tape in the TV/VCR. The tape must have a record tab.
- With ShowGuard, you don't have to worry about losing your timer recordings. If the power fails, programmed timer recordings will be restored when the clock is reset. (The clock will reset itself automatically if you are using the AUTO CLOCK feature. *Details are on pages 15-18.* If you are not using the AUTO CLOCK feature, reset the clock manually. *Details are on pages 13-14.*) The timer recording will not occur only if the timer recording was scheduled to take place during the power failure.
- Make sure DEFEAT RECORDING is set to OFF. *Details are on page 37.*

TV/VCR will not record.

- Make sure the tape has a record tab. *Details are on page five.*
- Make sure DEFEAT RECORDING is set to OFF. *Details are on page 37.*
- Plug the power cord into an active AC outlet. *Details are on page seven.*
- Check your hookups. *Details are on pages six-eight.*
- Set up the channels. *Details are on pages 11-12.*

The remote control is not available, or the remote control will not access the pop up menu.
- Use the buttons on the front panel of the TV/VCR to access the pop up menu. You can not enter numbers (for example, to program a timer recording) using the front panel buttons. *Details are on page 21.*

TV/VCR has no power.
- Make sure the power plug is completely connected to an AC (alternating current) outlet.

TV/VCR power shuts off after 15 minutes.
- To save energy, the TV/VCR will shut itself off after 15 minutes when it is on a channel that is not receiving a broadcast signal (for example, a station that has gone off the air for the night). This is normal.

Channel reception is poor.
- Check connections, then set up the channels again. *Details are on pages 11-12.*

TV/VCR does not have a picture.
- Adjust the antenna. *Details are on page six.*
- Adjust the TV/VCR picture controls. *Details are on pages 25-26.*

TV/VCR has poor sound or no sound.
- Adjust the volume.
- Press the MUTE button to restore the volume.

Tape playback is poor or tape is destroyed.
- Adjust the tracking. *Details are on page 47.*
- If moisture has accumulated in your TV/VCR, keep the power on for at least two hours, but do not try to play a tape. *Details are on page 50.*

Remote control does not operate TV/VCR.
- Aim the remote control directly at the TV/VCR's remote sensor. *Details are on pages five and 21.*
- Remove all obstacles between the remote control and the TV/VCR.
- Inspect and replace the batteries in the remote control. *Details are on page five.*

Number buttons won't work for channels above 69.
- Enter channel numbers as a two-digit number. If you want to select channels 100 and above, enter channel numbers as a three-digit number. *Details are on page 23.*
- If you are using an antenna, only channels 2-69 will be available.

A tape can't be inserted into the TV/VCR.
- Insert the tape window side up, with the record tab facing you.
- Make sure a tape isn't already in the TV/VCR by pressing the STOP/EJECT button on the TV/VCR.
- Gently push on the center of the tape. Never force a tape into the TV/VCR.
- If a timer recording is set and the TV/VCR power is off, the TV/VCR will eject the tape if the record tab is missing.
- Moisture may be present in the TV/VCR. If "DEW PROTECTION PLEASE WAIT" appears on the screen, you may not be able to insert a tape for several hours. *Details are on page 50.*

A tape can't be removed from the TV/VCR.
- Make sure the power plug is completely connected to an AC (alternating current) outlet.
- If a timer recording is programmed, turn on the TV/VCR power, then eject the tape. Be sure to insert a tape and turn off the TV/VCR power for the timer recording.

TV/VCR ejects the tape when you try to start a recording.
- Make sure the tape has a record tab. *Details are on page five.*

The cylinder rotates when tape playback is stopped.
- To enable the quick play mechanism, the cylinder will rotate for about five minutes. This is normal. The quick play mechanism switches the tape mechanism from Stop to Play in just one second.

Automatic clock setting won't work.
- Disconnect the car battery cord from the DC 13.2V jack. Instead, use the AC 120V jack to supply standard electrical power. *Details are on pages six-eight.*

RENEWED
90 DAY
LIMITED WARRANTY

a-b repeat play 39-40
accessories 56
ant(enna) jack 6-8, 22
audio jack 21, 32
automatic
  playback 47
  rewind 47

batteries 5
blue background 43
brightness, adjusting 25-26

channel
  above 100 23
  adding 12
  buttons 21, 24, 47
  deleting 12
  reviewing 12
  setup 11
clear button 23, 41
clock 13-18
color, adjusting 25-26
connections 6-8, 32
contents, table of 4
controls
  remote 23-24
  tv/vcr 21
counter only mode 27

daylight-savings time 19
dc 13.2v jack 8, 22
defeat recording 37
duplication 32

earphone jack 21

fast forward search 42
f.fwd/► button 23, 42
f.fwd button 21
front panel 21

glossary 49

helpful hints 50-51
hookups 6-8, 32

language selection 10
line input mode 11, 32, 49
long play 30, 49
lp 30, 49
memory
  button 24, 40-41
  real-time counter 41
  rewind, power off 47
menu
  button 24
  front panel button access . .21
mute button 23

number buttons 23

one-touch recording 31

pause/still button 24, 42
picture, adjusting 25-26
play button 21, 23
playback options 42
playing 29
power
  button 21, 23
  cord 7-8, 22

real-time counter memory . . .41
rear panel 22
rec/otr button 21, 24
record light 21
recording 30
recording prevention 5
reminder 28
remote
  control
    buttons 23-24
    using 5
  sensor 21
repeat play 38
rerecording 32
reverse search 42
rew(ind) button 21
rew(ind)/◄ button 24, 42
rewinding 29

safety precautions 3
searching 42
sensor (remote) 21
sharpness, adjusting 25-26
showguard 33, 36, 50
sleep timer 44
slp 30, 49
smartclock 15-18
sp 30, 49
specifications 48
sqpb 29
standard play 30, 49
status display 27
status/exit button 24, 27
still picture 42
stop/▼ button 24
stop/eject button 21
super high speed searching . . .42
super long play 30, 49

table of contents 4
tape
  duplication 32
  speed 30, 49
time
  setting 13-18
  zone 20
timer recording
  cancelling 36
  reviewing 36
  setting 33-35
tint, adjusting 25-26
tracking 47

video jack 21, 32
volume bar 46

wake up timer 45
warranty 52

SUPPLIED ACCESSORIES

The following items are supplied with your TV/VCR; they are provided to help you use or set up your TV/VCR.



Remote Control for CCB092
4835 218 37272
Two AA Batteries 4835 138 17012

Indoor (VHF) Rod Antenna
4835 303 37006



Detachable AC Cord 4835 321 17141



Car Battery Cord 4835 321 57008

OPTIONAL ACCESSORIES

The following additional items are not provided with your TV/VCR, but they are designed for use with your new TV/VCR. To order these optional accessories, contact us at:

Philips Parts & Accessories Marketing Department
401 East Old Andrew Johnson Highway
P.O. Box 555
Jefferson City, TN 37760
1-800-851-8885.

VHS Cassette Rewinder
#M61117



Monaural Audio and Video Cables (6 feet)
Color-coded for easy connection
#M61103



Three Cassette Storage Cases (plastic)
Fits VHS and Beta cassettes
#M61104

Six High-grade, VHS, T-120 Cassettes
#MHG1206

This owner's manual is made of recycled paper.

As an ENERGY STAR® Partner, Philips Consumer Electronics Company has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.
ENERGY STAR® is a U.S. registered mark.

IB8210E001
Printed In Malaysia
0EMN01671 / T4108UJ * * * * *